


# TRAVEL & WALL ADAPTERS



02004



## Universal Travel Adapter

- ▶ For use in Australia
- ▶ RCM Australian Standards
- ▶ Suitable for UK, EU & US type plugs and devices.

02509



## 2-way Universal Adapter

- ▶ For use in Australia
- ▶ RCM Australian Standards
- ▶ 2 socket types to cover most countries in the world

02516



## Indian/ Sth Africa Adapter

- ▶ For use in Australia
- ▶ RCM Australian Standards
- ▶ Suitable for India, South Africa or parts of Middle East type plugs and devices

02028



## Outbound US Adapter

- ▶ RCM Australian Standards
- ▶ For use in US, Canada, Thailand, parts of Asia & South America

02042



## Outbound UK Adapter

- ▶ RCM Australian Standards
- ▶ For use in UK, Singapore, Hong Kong, Asia, Africa & Middle East

02523



## Outbound India Adapter

- ▶ RCM Australian Standards
- ▶ For use in India, Pakistan & Sri Lanka

02035



## Outbound EU Adapter

- ▶ RCM Australian Standards
- ▶ For use in Europe, Bali, Asia, Parts of Middle East & South America

02059



## Double Adaptor

- ▶ RCM Australian Standards
- ▶ Overheating Protection



[www.eastrade.net.au](http://www.eastrade.net.au)

1300 225 206